


## Virucidal procedure for the disinfection of surfaces using the Freedom® Pure and Freedom® machines (EN14476\* Virucide standard):

### For 600 ml of mixture (spray bottle capacity):

	FREEDOM® PURE	FREEDOM®
<p><b>Number of activations:</b> <b>4 cycles</b> (duration of each cycle: 5 min).</p>	<p>&gt; 2 level white spoonfuls of salt</p> 	<p>&gt; 1 level white spoonful of salt</p> 
<p><b>Caution:</b> <b>15 min of downtime</b> between each cycle.</p>	<p>&gt; Press 2 consecutive times to activate "High" mode</p>	<p>&gt; Press 1 time (single mode - equivalent to "High")</p>

If the hydrolysis system does not engage, add 400 ml of water to obtain 1 litre to dilute the solution (do not add water).

- Stir the solution well with the large spoon to dissolve the salt.
- Between each activation, remove the container from the base for at least 15 minutes, and disconnect the plug from its base to enable the machine to cool more quickly.
- Reactivate the solution every 3 days by activating it **one time (do not add salt)** - Press 2 times (High) on a Freedom® Pure, 1 time (High) on a Freedom®.
- Keep the spray bottle away from light and heat.
- Regularly descale the inside of the container with vinegar.
- When not being used, never leave the container on its base, whether empty or full.

 **Remember that the machines (Freedom® Pur + Freedom®) are not designed to make virucidal solution at a regular rate. Please only prepare the solution in case of a risky situation.**

Above all, observe the rules set by the Federal Office of Public Health (FOPH): Stay at home, wash your hands regularly and thoroughly, practice social distancing, avoid shaking hands, cough or sneeze into a tissue or inside your elbow, and always call before visiting the doctor's office or emergency room.

We have received FOPH approval that our solution is a virucide and bactericide (EN1276, EN1650, EN13697, EN13727 and EN14476 standards, all tested in both clean and contaminated conditions). It is registered under the number CHZN5805.

(\*Poliovirus, Murine Norovirus, Adenovirus / In contaminated conditions of 2,000 ppm or 5 activations).

**We remain available to serve you. Feel free to contact us at [info@aquama.ch](mailto:info@aquama.ch) and take care of yourself!**