



Use of a Hogeron® aquama® via RFID badges

The RFID system replaces the need to use a mobile application when you want to restock the aquama® solution.

You should know that even if the machine has this system, it is possible to use the aquama® application to extract the solution.

You will find two models of RFID card to use with machines equipped with this system.



> **SPRAY card**

This card is used to extract the solution to fill a spray bottle.

1. Unscrew the spray head from the body of the bottle.
2. Place the spray under the spout.
3. Place the card directly on the round plastic plate on the top left of the machine.
4. Upon contact, the plate lights up with a blue LED.
5. The spray bottle is filled instantly.
6. Remove the RFID card from the plate to stop filling the spray.

PLEASE NOTE: it does not stop automatically at 600ml.



> **NOZZLE card**

This card makes it possible to fill a container with solution via the gun located on the right of the machine.

1. With one hand, take the pistol that hangs from a hook on the right side of the machine.
2. Orient it over the container.
3. First press the trigger (it is possible to block it by pressing the red notch).
4. With the other hand, place the card directly on the round plastic plate which is located on the top left of the machine.
5. Upon contact, the plate lights up with a blue LED.
6. The gun is activated immediately.
7. Remove the RFID card from the plate to stop the gun.
8. Release the trigger after (this prevents the gun from remaining under pressure).
9. Put the gun back in place.



If the badges should be lost or broken, please notify us directly so that we can deactivate them.

Consumption will be automatically debited from the customer account to which the card belongs.

Account available on <https://aquama.ch/fr/Mon-compte>